
WARRANTY

ELECTROMATIC Equipment Co., Inc. (ELECTROMATIC) warrants to the original purchaser that this product is of merchantable quality and confirms in kind and quality with the descriptions and specifications thereof. Product failure or malfunction arising out of any defect in workmanship or material in the product existing at the time of delivery thereof which manifests itself within one year from the sale of such product, shall be remedied by repair or replacement of such product, at ELECTROMATIC's option, except where unauthorized repair, disassembly, tampering, abuse or misapplication has taken place, as determined by ELECTROMATIC. All returns for warranty or non-warranty repairs and/or replacement must be authorized by ELECTROMATIC, in advance, with all repacking and shipping expenses to the address below to be borne by the purchaser.

THE FOREGOING WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE WARRANTY OF MERCHANTABILITY AND FITNESS FOR ANY PARTICULAR PURPOSE OR APPLICATION. ELECTROMATIC SHALL NOT BE RESPONSIBLE NOR LIABLE FOR ANY CONSEQUENTIAL DAMAGE, OF ANY KIND OR NATURE, RESULTING FROM THE USE OF SUPPLIED EQUIPMENT, WHETHER SUCH DAMAGE OCCURS OR IS DISCOVERED BEFORE, UPON OR AFTER REPLACEMENT OR REPAIR, AND WHETHER OR NOT SUCH DAMAGE IS CAUSED BY MANUFACTURER'S OR SUPPLIER'S NEGLIGENCE WITHIN ONE YEAR FROM INVOICE DATE.

Some State jurisdictions or States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you. The duration of any implied warranty, including, without limitation, fitness for any particular purpose and merchantability with respect to this product, is limited to the duration of the foregoing warranty. Some states do not allow limitations on how long an implied warranty lasts but, not withstanding, this warranty, in the absence of such limitations, shall extend for one year from the date of invoice.

ELECTROMATIC Equipment Co., Inc.
600 Oakland Ave. Cedarhurst, NY 11516—USA
Tel: 1-800-645-4330/ Tel: 516-295-4300/ Fax: 516-295-4399

Every precaution has been taken in the preparation of this manual. Electromatic Equipment Co., Inc., assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of information contained herein. Any brand or product names mentioned herein are used for identification purposes only, and are trademarks or registered trademarks of their respective holders.

WARRANTY

ELECTROMATIC Equipment Co., Inc. (ELECTROMATIC) warrants to the original purchaser that this product is of merchantable quality and confirms in kind and quality with the descriptions and specifications thereof. Product failure or malfunction arising out of any defect in workmanship or material in the product existing at the time of delivery thereof which manifests itself within one year from the sale of such product, shall be remedied by repair or replacement of such product, at ELECTROMATIC's option, except where unauthorized repair, disassembly, tampering, abuse or misapplication has taken place, as determined by ELECTROMATIC. All returns for warranty or non-warranty repairs and/or replacement must be authorized by ELECTROMATIC, in advance, with all repacking and shipping expenses to the address below to be borne by the purchaser.

THE FOREGOING WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE WARRANTY OF MERCHANTABILITY AND FITNESS FOR ANY PARTICULAR PURPOSE OR APPLICATION. ELECTROMATIC SHALL NOT BE RESPONSIBLE NOR LIABLE FOR ANY CONSEQUENTIAL DAMAGE, OF ANY KIND OR NATURE, RESULTING FROM THE USE OF SUPPLIED EQUIPMENT, WHETHER SUCH DAMAGE OCCURS OR IS DISCOVERED BEFORE, UPON OR AFTER REPLACEMENT OR REPAIR, AND WHETHER OR NOT SUCH DAMAGE IS CAUSED BY MANUFACTURER'S OR SUPPLIER'S NEGLIGENCE WITHIN ONE YEAR FROM INVOICE DATE.

Some State jurisdictions or States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you. The duration of any implied warranty, including, without limitation, fitness for any particular purpose and merchantability with respect to this product, is limited to the duration of the foregoing warranty. Some states do not allow limitations on how long an implied warranty lasts but, not withstanding, this warranty, in the absence of such limitations, shall extend for one year from the date of invoice.

ELECTROMATIC Equipment Co., Inc.
600 Oakland Ave. Cedarhurst, NY 11516—USA
Tel: 1-800-645-4330/ Tel: 516-295-4300/ Fax: 516-295-4399

Every precaution has been taken in the preparation of this manual. Electromatic Equipment Co., Inc., assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of information contained herein. Any brand or product names mentioned herein are used for identification purposes only, and are trademarks or registered trademarks of their respective holders.

TABLE OF CONTENTS

1.0	Introduction	2
2.0	Power Key - ON / OFF	2
3.0	Display	3
4.0	Measurement	4
5.0	Selecting the unit of measure	5
6.0	Verifying gauge accuracy	5
7.0	Meathods of measurment and standards	6
8.0	Technical data	7
9.0	Warranty	8

TABLE OF CONTENTS

1.0	Introduction	2
2.0	Power Key - ON / OFF	2
3.0	Display	3
4.0	Measurement	4
5.0	Selecting the unit of measure	5
6.0	Verifying gauge accuracy	5
7.0	Meathods of measurment and standards	6
8.0	Technical data	7
9.0	Warranty	8

1.0 INTRODUCTION

PaintCheck is a Paint Thickness Gauge especially suited for car bodies. It non-destructively measures coatings, e.g. lacquer, paint, plastic, rubber, enamel etc., on iron/steel and on non-ferrous metals such as aluminium.

PaintCheck automatically recognizes the base material (iron/steel or non-ferrous metal) and then displays the correct coating thickness. In addition, with "Ferr" or "Non-Ferr," the display indicates whether measurement was made on iron/steel or on non-ferrous metal.



2.0 POWER KEY - ON / OFF

Switching On: Press the **Power Key** briefly.

Switching Off: Press AND HOLD the **Power Key** for about 2 seconds.

Auto Off: 1.5 min after the last measurement.



8.0 TECHNICAL DATA

Measuring range	0" – 0.08" (0 – 2mm)
Tolerance	±5 µm (+5% of readings)
Resolution	0 – 500 µm 5 µm 500 µm – 1,000 µm 10 µm 1,000 µm – 2,000 µm 25 µm
Display/height of digits	4-digits / 0.39" (10mm)
Minimum measuring area	1.57" x 1.57" (40mm x 40mm)
Minimum curvature radius	convex 1.97" (25mm) concave .98" (50mm)
Minimum substrate thickness	iron/steel 2.95" (0.75mm) non-ferrous metal .98" (0.25mm)
Calibration	not necessary
Temperature range	32 – 122 °F (0 – 50 °C)
Surface temperature of specimen	59 – 140 °F (15 – 60 °C)
Power supply	2 x Micro (AAA) 1.5V
Dimensions	4.3" x 1.97" x .98" (110 x 50 x 25mm)
Weight incl. batteries	0.2 lbs. (90 g)
Protection class	IP52 protection against dust and dripping water

1.0 INTRODUCTION

PaintCheck is a Paint Thickness Gauge especially suited for car bodies. It non-destructively measures coatings, e.g. lacquer, paint, plastic, rubber, enamel etc., on iron/steel and on non-ferrous metals such as aluminium.

PaintCheck automatically recognizes the base material (iron/steel or non-ferrous metal) and then displays the correct coating thickness. In addition, with "Ferr" or "Non-Ferr," the display indicates whether measurement was made on iron/steel or on non-ferrous metal.



2.0 POWER KEY - ON / OFF

Switching On: Press the **Power Key** briefly.

Switching Off: Press AND HOLD the **Power Key** for about 2 seconds.

Auto Off: 1.5 min after the last measurement.



8.0 TECHNICAL DATA

Measuring range	0" – 0.08" (0 – 2mm)
Tolerance	±5 µm (+5% of readings)
Resolution	0 – 500 µm 5 µm 500 µm – 1,000 µm 10 µm 1,000 µm – 2,000 µm 25 µm
Display/height of digits	4-digits / 0.39" (10mm)
Minimum measuring area	1.57" x 1.57" (40mm x 40mm)
Minimum curvature radius	convex 1.97" (25mm) concave .98" (50mm)
Minimum substrate thickness	iron/steel 2.95" (0.75mm) non-ferrous metal .98" (0.25mm)
Calibration	not necessary
Temperature range	32 – 122 °F (0 – 50 °C)
Surface temperature of specimen	59 – 140 °F (15 – 60 °C)
Power supply	2 x Micro (AAA) 1.5V
Dimensions	4.3" x 1.97" x .98" (110 x 50 x 25mm)
Weight incl. batteries	0.2 lbs. (90 g)
Protection class	IP52 protection against dust and dripping water

7.0 METHODS OF MEASUREMENT AND STANDARDS

PaintCheck operates with the magnetic-inductive and the eddy current methods. It corresponds to the following standards:


Magnetic method:

DIN EN ISO 2808,
DIN EN ISO 2178,
ASTM B499,
DIN 50 982
ISO 19840

Eddy current method:

DIN EN ISO 2808,
DIN EN ISO 2360,
ASTM D1400

3.0 DISPLAY



7.0 METHODS OF MEASUREMENT AND STANDARDS

PaintCheck operates with the magnetic-inductive and the eddy current methods. It corresponds to the following standards:


Magnetic method:

DIN EN ISO 2808,
DIN EN ISO 2178,
ASTM B499,
DIN 50 982
ISO 19840

Eddy current method:

DIN EN ISO 2808,
DIN EN ISO 2360,
ASTM D1400

3.0 DISPLAY



4.0 MEASUREMENT

After switching on the gauge, either four dashes *or* the last measurement value will appear on the display.

At this point, you can immediately start to measure. Position the instrument on the surface to be measured and new thickness value will appear on the display.

NOTE: After each measurement, lift the instrument a minimum of 0.12 in. (3 cm) from the measurement surface before you take another measurement.




5.0 SELECTING THE UNIT OF MEASURE

1. Note the current measuring unit.
2. Switch the instrument OFF.
3. Switch on the instrument ON with the Power Key and keep this key pressed until a beep sound is heard.
4. Release the key and the instrument will be switched switches into the other unit of measure: either from μm to mils or the vice versa.

6.0 VERIFYING GAGUE ACCURACY

You can check the accuracy of the instrument using the included zero plates "Fe" or "NFE" and the supplied measurement calibration standard. The permitted measurement tolerance is given in the Technical Data (section 8.0).



4.0 MEASUREMENT

After switching on the gauge, either four dashes *or* the last measurement value will appear on the display.

At this point, you can immediately start to measure. Position the instrument on the surface to be measured and new thickness value will appear on the display.

NOTE: After each measurement, lift the instrument a minimum of 0.12 in. (3 cm) from the measurement surface before you take another measurement.




5.0 SELECTING THE UNIT OF MEASURE

1. Note the current measuring unit.
2. Switch the instrument OFF.
3. Switch on the instrument ON with the Power Key and keep this key pressed until a beep sound is heard.
4. Release the key and the instrument will be switched switches into the other unit of measure: either from μm to mils or the vice versa.

6.0 VERIFYING GAGUE ACCURACY

You can check the accuracy of the instrument using the included zero plates "Fe" or "NFE" and the supplied measurement calibration standard. The permitted measurement tolerance is given in the Technical Data (section 8.0).



PaintCheck

Coating Thickness Gauge



Operating Instructions



ELECTROMATIC
EQUIPMENT CO., INC.

600 Oakland Ave., Cedarhurst, NY 11516-U.S.A.
TEL: 516-295-4300 • FAX: 516-295-4399

www.checkline.com

PaintCheck

Coating Thickness Gauge



Operating Instructions



ELECTROMATIC
EQUIPMENT CO., INC.

600 Oakland Ave., Cedarhurst, NY 11516-U.S.A.
TEL: 516-295-4300 • FAX: 516-295-4399

www.checkline.com